

Lunar Advanced Volatile Analysis Subsystem: Pressure Transducer Trade Study

Edward Shinuk Kang
NASA Kennedy Space Center
Mechanical Engineering
NE-M1 Spring Session
Date: 19 04 2017

Mentors: Katherine Cryderman & Janine Captain

Lunar Advanced Volatile Analysis Subsystem: Pressure Transducer Trade Study

Edward Shinuk Kang¹

NASA John F. Kennedy Space Center, Kennedy Space Center, FL 32899

In Situ Resource Utilization (ISRU) is a key factor in paving the way for the future of human space exploration. The ability to harvest resources on foreign astronomical objects to produce consumables and propellant offers potential reduction in mission cost and risk. Through previous missions, the existence of water ice at the poles of the moon has been identified, however the feasibility of water extraction for resources remains unanswered. The Resource Prospector (RP) mission is currently in development to provide ground truth, and will enable us to characterize the distribution of water at one of the lunar poles.

Regolith & Environment Science and Oxygen & Lunar Volatile Extraction (RESOLVE) is the primary payload on RP that will be used in conjunction with a rover. RESOLVE contains multiple instruments for systematically identifying the presence of water. The main process involves the use of two systems within RESOLVE: the Oxygen Volatile Extraction Node (OVEN) and Lunar Advanced Volatile Analysis (LAVA). Within the LAVA subsystem, there are multiple calculations that depend on accurate pressure readings. One of the most important instances where pressure transducers (PT) are used is for calculating the number of moles in a gas transfer from the OVEN subsystem. As a critical component of the main process, a mixture of custom and commercial off the shelf (COTS) PTs are currently being tested in the expected operating environment to eventually down select an option for integrated testing in the LAVA engineering test unit (ETU).

Nomenclature

| | | |
|----------------|---|---|
| <i>%RSD</i> | = | Percent Relative Standard Deviation |
| <i>Al</i> | = | Aluminum |
| <i>C</i> | = | Degrees Celsius |
| <i>DAQ</i> | = | Data Acquisition |
| <i>ETU</i> | = | Engineering Test Unit |
| <i>FSS</i> | = | Fluid Subsystem |
| <i>GC-MS</i> | = | Gas Chromatograph – Mass Spectrometer |
| <i>GSS</i> | = | Gas Supply System |
| <i>HA</i> | = | House Air |
| <i>He</i> | = | Helium |
| <i>ISRU</i> | = | In Situ Resource Utilization |
| <i>LAVA</i> | = | Lunar Advanced Volatile Analysis |
| <i>OVEN</i> | = | Oxygen Volatile Extraction Node |
| <i>PID</i> | = | Proportional – Integral – Derivative |
| <i>PSIA</i> | = | Pounds per Square Inch - Absolute |
| <i>PT</i> | = | Pressure Transducer |
| <i>RESOLVE</i> | = | Regolith & Environment Science and Oxygen & Lunar Volatile Extraction |
| <i>RP</i> | = | Resource Prospector |
| <i>RT</i> | = | Room Temperature |
| <i>SD</i> | = | Standard Deviation |
| <i>SS</i> | = | Stainless Steel |

¹NIFS Intern, NE-M1, NASA Kennedy Space Center, University of Texas at El Paso.

I. Introduction

In Situ Resource Utilization (ISRU) is a key factor in paving the way for the future of human space exploration. The ability to harvest resources on foreign astronomical objects to produce consumables and propellant offers potential reduction in mission cost and risk. Although the existence of water ice at the poles of the moon has been identified, the question of how feasible the resource is to extract still remains unanswered. The Resource Prospector (RP) mission is currently in development to provide ground truth and will enable us to characterize the distribution of water at one of the lunar poles.

Regolith & Environment Science and Oxygen & Lunar Volatile Extraction (RESOLVE) is the primary payload, paired with a rover, which contains multiple instruments that will be used to systematically identify the presence of water. The main process involves the use of two systems within RESOLVE: the Oxygen Volatile Extraction Node (OVEN) and Lunar Advanced Volatile Analysis (LAVA). The OVEN will retrieve the lunar regolith sample from the drill to weigh and heat. Once this process is completed, the volatiles that evolve from the heated soil are transferred to the LAVA Fluid Subsystem (FSS). The volatiles are stored in the surge tank for recording of pressure and temperature measurements, and are then evaluated by the Gas Chromatograph – Mass Spectrometer (GC-MS). The GC-MS analytically identifies and quantifies the volatiles so that we are able to identify water and other species that may be useful.

II. Pressure Transducer Trade Study

Within the LAVA subsystem, there are multiple calculations that depend on accurate pressure readings. One of the most important instances where Pressure Transducers (PT) are used is for calculating the number of moles in a gas transfer from the OVEN subsystem. As a critical component of the Volatile Analysis process, a mixture of custom and commercial off the shelf (COTS) PTs are currently being tested in the expected operating environment to eventually down select an option for integrated testing in the LAVA engineering test unit (ETU). This report is a continuation of an existing trade study¹, and will concentrate on the data processing and analysis of eleven PTs. In addition, alterations made to the test setup since the beginning of 2017 will also be discussed.

A. Methods

In an attempt to better understand the effects of heat, vacuum, and helium exposure on the PTs' behavior, the units, outlined below in Tables 1 and 2 and shown in Figure 1, are being thoroughly tested in vacuum at roughly 1.0×10^{-3} Torr. They are exposed to three different conditions: room temperature (RT) house air (HA), 152C house air (HA), and 152C helium (He) at multiple pressure steps. It is expected that 152C He represents the worst-case scenario since helium molecules are smaller than air molecules and have the potential to leak across the diaphragm of the PTs causing degraded performance. Furthermore, the sensors were tested in two manifolds, stainless steel 316 and aluminum 6061, to identify any effects that may result from the different contact materials.




Figure 1. The manifold on the left is stainless steel and the one on the right is aluminum.

With the exception of the GP50 189, both manifolds have identical PTs installed. The GP50 189 has a much larger pressure range than the others, but required evaluation in the trade study due to its low mass and potential use in the high-pressure gas delivery system within LAVA. It is also important to note that the MEMScap PTs were not originally selected for testing, and as a result, were incorporated into the trade study several months late. These sensors offer extremely small and light profiles; however, they were not tested beyond 125C by the vendor. As a fairly simple addition to the original setup, the MEMScap PTs were integrated to test their capabilities at 152C.

| Name | Port Designation | Pressure Range (psia) | Mass (g) with wiring |
|----------------------------------|------------------|-----------------------|----------------------|
| Measurement Specialties XPC10 #1 | PT-001 | 0 to 150 | 42.30 |
| Tecsis XPMF03 #1 | PT-002 | 0 to 100 | 29.44 |
| GP50 7900 #1 (amplified) | PT-005 | 0 to 100 | 78.92 |
| GP50 189 | PT-007 | 14.7 to 514.7 | 14.35 |
| MEMScap SP81 R #1 | PT-003 | 0 to 145 | 10.04 |
| MEMScap SP80 D #1 | PT-007 | 0 to 145 | 12.30 |

Table 1. PTs specifications on stainless steel manifold.

| Name | Port Designation | Pressure Range (psia) | Mass (g) with wiring |
|----------------------------------|------------------|-----------------------|----------------------|
| Measurement Specialties XPC10 #2 | PT-009 | 0 to 150 | 42.30 |
| Tecsis XPMF03 #2 | PT-010 | 0 to 100 | 29.44 |
| GP50 7900 #2 (amplified) | PT-013 | 0 to 100 | 78.92 |
| MEMScap SP81 R #2 | PT-012 | 0 to 145 | 10.04 |
| MEMScap SP80 D #2 | PT-014 | 0 to 145 | 12.30 |

Table 2. PTs specifications on aluminum manifold.

The trade study is comprised of two types of test cycles, a thermal vacuum cycle and a full test cycle. Typically, a thermal vacuum cycle is run four times per week and a full test cycle is run once per week. The thermal vacuum cycle consists of heating the manifolds to operating temperatures and allowing them to thermally soak for about one and a half hours. The thermal cycles are important as it replicates the numerous thermal cycles the LAVA subsystem will undergo. In addition, the manifolds are brought to operating temperature to consistently induce thermal stress onto the PTs and to investigate how the wear effects the PT's repeatability. Additional background on the trade study purpose and test setup can be found in the previous trade study report¹.

The full test cycle consists of ramping through pressure steps, as seen below in Figure 2 column "A", via manual adjustments of the pressure source (house air or helium) to create calibration curves for each PT. To accurately read the pressure within the manifolds, a calibrated Paroscientific pressure standard is used. Using LabVIEW system design software paired with Data Acquisition (DAQ) cards, we record the raw voltage output values from the PTs and the pressure readings from the Paroscientific pressure sensor in Microsoft Excel spreadsheets. Although we record test data from thermal vacuum cycles in case of any anomalies, we are mainly concentrated on processing and analyzing the data from the full test cycles. We use Microsoft Excel macros to process and plot the raw data. An example of the processed data is shown below in Figure 2.




Figure 2. Processed data for PT-001 from Test 25.

At each pressure step, we aim to acquire about 90 seconds' worth of data at a rate of one data point per second. This time duration is sufficient for the system to stabilize and to gather enough reliable data points at each step. Columns B and C list average pressure readings from the Paroscientific and average voltage readings from the PTs, respectively, for the room temperature (RT) house air (HA) cycle. Note the multiple tabs along the bottom of the spreadsheet for each PT. The same pattern follows for the next four columns for 152C HA and 152C He. The macro sifts through raw data and averages 30 data points out of the 90 at every pressure step. Again, the values listed in columns B, D and F are averages. The macro averages using the following two requirements: 1) skip the first 30 points at each pressure step to reach the more stable region of data, and 2) do not average until 30 sequential pressure data points are within 0.1psia of each other. Next, the macro plots data sets at each environmental condition by voltage versus pressure. By plotting the experimental data sets for each environmental condition, we are able to characterize each PT using its trend lines (calibration curve) and R^2 (correlation coefficient) values. Available factory calibration curves are plotted for comparison between experimental trend lines, however they are not entirely helpful as they do not always specify the environmental conditions at which the calibration curves were made.

B. Results and Discussion

The results are reflective of 25 full test cycles performed over the course of five months. Upon processing the raw data using Excel macros, we were left with trend lines for each test cycle in each test environment for all of the pressure sensors. The data for PT-001 Measurement Specialties in the stainless steel manifold at 152C Helium is shown below and represents one data set, but for ease of explanation is separated into four tables (Tables 3-6).

PT-001 Measurement Specialties (SS) 152C He

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|----------------|----------------|------------------|----------------|
| Factory | 12386 | - | 1 |
| 1 | 11772 | 0.6791 | 1 |
| 2 | 11820 | 0.2544 | 0.9996 |
| 3 | - | - | - |
| 4 | 11768 | 0.3496 | 1 |
| 5 | - | - | - |
| 6 | 11764 | 0.0643 | 1 |
| 7 | 11761 | -0.0414 | 1 |
| 8 | 11761 | -0.2843 | 1 |
| 9 | 11773 | -0.4704 | 1 |
| 10 | 11769 | -0.1253 | 1 |
| 11 | 11769 | 0.0647 | 1 |
| 12 | 11765 | 0.2504 | 1 |
| 13 | 11770 | 0.5007 | 1 |
| 14 | - | - | - |
| 15 | 11775 | 1.0364 | 1 |
| 16 | 11772 | 1.1477 | 1 |
| 17 | 11762 | 0.0535 | 1 |
| 18 | 11789 | 0.0797 | 1 |
| 19 | 11790 | 0.2291 | 1 |
| 20 | 11806 | 0.7983 | 1 |
| 21 | 11830 | 0.8718 | 1 |
| 22 | 11885 | 0.9048 | 1 |
| 23 | 11781 | 1.165 | 1 |
| 24 | 11942 | 0.7318 | 1 |
| 25 | 11883 | 1.0795 | 1 |

Table 3. Trend lines from plotting experimental data

| | | | |
|----------------|-------------|-------------|----------|
| Range | 181 | 1.6354 | 0.0004 |
| Average | 11795.77273 | 0.424518182 | 0.999982 |
| SD | 47.47145728 | 0.479190046 | 8.33E-05 |
| %RSD | 0.402444659 | 112.8785684 | 0.008332 |

Table 4. Statistical data of trend lines

| 3 psia | 10 psia | 65 psia |
|--------|---------|---------|
| 3 | 10 | 65 |
| 3.530 | 10.183 | 62.457 |
| 3.117 | 9.797 | 62.284 |
| - | - | - |
| 3.200 | 9.851 | 62.106 |
| - | - | - |
| 2.914 | 9.562 | 61.800 |
| 2.807 | 9.454 | 61.679 |
| 2.564 | 9.211 | 61.436 |
| 2.381 | 9.035 | 61.313 |
| 2.725 | 9.377 | 61.637 |
| 2.915 | 9.567 | 61.827 |
| 3.100 | 9.749 | 61.991 |
| 3.351 | 10.003 | 62.268 |
| - | - | - |
| 3.888 | 10.543 | 62.830 |
| 3.999 | 10.652 | 62.926 |
| 2.902 | 9.550 | 61.779 |
| 2.935 | 9.598 | 61.947 |
| 3.085 | 9.748 | 62.101 |
| 3.658 | 10.330 | 62.755 |
| 3.737 | 10.423 | 62.954 |
| 3.783 | 10.500 | 63.276 |
| 4.018 | 10.677 | 62.990 |
| 3.624 | 10.373 | 63.402 |
| 3.958 | 10.673 | 63.440 |

Table 5. Pressure outputs based on factory curve voltages at 3, 10, 65 psia

| | | |
|----------|-------------|-------------|
| 1.637338 | 1.641858905 | 2.127164654 |
| 1.637 | 9.947990431 | 62.3270878 |
| 0.484617 | 0.498082082 | 0.634148931 |
| 29.59785 | 5.006861294 | 1.017453171 |

Table 6. Statistical data of theoretical pressures

To view test data for RT HA, 152C HA, and the rest of 152C He, refer to the “Appendix”.

Table 3 shown above contains the collection of all trend lines separated into test, slope, intercept, and R^2 values. Table 4 contains the range, average, standard deviation (SD), and percent relative standard deviation (%RSD) for the trend lines in Table 3. Table 5 contains theoretical pressures with respect to the experimental trend lines (will go into more depth in upcoming sections). Table 6 contains the range, average, SD, and %RSD of the theoretical pressures.

Making any sort of selection based on linearity is difficult since all of the sensors displayed R^2 values that were more or less indicative of straight lines. However, by analyzing the range, average and standard deviation of the slope and intercept data for each sensor over the five months, we were able to identify the top contenders.

One issue when comparing several types of PTs is the varying output range from each sensor. Depending on the scale of the output, a small deviation in the calibration curve can mean a large pressure variation. In an attempt to translate the deviations into percentages for easier comparison across the multiple sensors, we tried using percent relative standard deviation (%RSD). While %RSD was helpful, it was difficult to interpret and translate into practical meaning. The %RSD values were not useful when dealing with very small numbers. In order to “quantify” the deviation in numbers that we can compare and understand in terms of pressure, we used the factory calibration curve for each individual sensor to determine the theoretical voltage outputs at low (3psia), medium (10psia) and high (65psia) pressures. Given that each trend line represents a line function, $y = mx+b$, with “y” being output pressure, “m” being slope, “x” being voltage and “b” being the intercept, we were able to back calculate the expected voltage by plugging in fixed output pressures (3, 10 and 65 psia). Using the expected voltages obtained from the factory curves, we plugged them into all of the experimental calibration curves for Tests 1-25 and were able to compute theoretical pressure values. Although this method does not precisely indicate how accurate a sensor may be, it does provide a good idea of how much a sensor is drifting over time.

The following tables, 7 and 8, show the top two candidates: PT-001 Measurement Specialties and PT-002 Tecsis with 152C Helium in the stainless steel manifold.

PT-001 Measurement Specialties (SS) 152C He

| | Slope (psia/V) | Intercept (psia) | R^2 | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------|----------|-------------|-------------|
| Range | 181 | 1.6354 | 0.0004 | 1.637338 | 1.641858905 | 2.127164654 |
| Average | 11795.77273 | 0.424518182 | 0.999982 | 1.637 | 9.947990431 | 62.3270878 |
| SD | 47.47145728 | 0.479190046 | 8.33E-05 | 0.484617 | 0.498082082 | 0.634148931 |
| %RSD | 0.402444659 | 112.8785684 | 0.008332 | 29.59785 | 5.006861294 | 1.017453171 |

Table 7. Data analysis table of PT-001

PT-002 Tecsis (SS) 152C He

| | Slope (psia/V) | Intercept (psia) | R^2 | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------|----------|-------------|-------------|
| Range | 487 | 2.6632 | 0.0004 | 2.568181 | 2.384861535 | 1.059901936 |
| Average | 18465.22727 | -0.247504545 | 0.999964 | 2.568 | 10.30605402 | 64.91927729 |
| SD | 140.746365 | 0.706328181 | 8.81E-05 | 0.679222 | 0.627015225 | 0.229498985 |
| %RSD | 0.762223843 | -285.3798826 | 0.008814 | 26.44761 | 6.083950504 | 0.353514387 |

Table 8. Data analysis table of PT-002

Based on %RSD and the ranges of the theoretical pressures at 3, 10, and 65 psia, Measurement Specialties is the clear winner. However, this was dismissed when we took additional factors into account. Since minimizing mass is a driving requirement, the Tecsis units are 13 grams lighter and preferable to the Measurement Specialties units. Although Measurement Specialties produced slightly better results, there were not any distinguishable trends in its drift over time, as shown in Figure 3 below. On the contrary, Tecsis shows a predictable and consistent drift throughout the entire testing period, as shown in Figure 4 below. Tecsis also shows consistency in its counterpart sensor, PT-010, shown in Figure 6, being tested in the aluminum manifold; this produced data very similar to the stainless-steel sensor. It is important to have this consistency because it allows us to account for its drift more easily during flight if we cannot recalibrate. As a result, the team down selected Tecsis as the best option for ETU testing.




Figure 3. Test # vs Intercept plot for PT-001; notice the random pattern in the drift.




Figure 4. Test # vs Intercept plot for PT-002; notice the predictable pattern in the drift.




Figure 5. Test # vs Intercept plot for PT-009; notice differing trend from its counterpart, PT-001.




Figure 6. Test # vs Intercept plot for PT-010; notice consistent trend with its counterpart, PT-002.

C. Additional Findings

Throughout the trade study, there were several occasions when the system leak rate fell out of tolerance. Our standard procedure for trouble shooting a leak consists of pressurizing the system with helium or house air and using Snoop, a soapy leak check fluid, or a helium detector to find the source of the leak. Ports on the manifolds without sensors are plugged using special bolts with Viton O-rings shown in Figure 7. Over time, due to the constant fluctuation of temperature during thermal cycling, the O-rings expand and contract. This constant change is observed to result in wear, eventually causing the O-ring to lose its seal.




Figure 7. The left shows an empty port and the right shows the matching Viton O-ring plug.

As previously mentioned, the MEMScap PTs were an addition we made late into the trade study. Although the test manifolds were designed to accommodate various port sizes, they could not support the MEMScap sensors without an adapter. We used 4mm to 10-32 Beswick compression fittings to integrate the MEMScap sensors to the manifolds. As a result of the fitting extension, the MEMScap sensors were further away from the heat traced manifolds compared to the other sensors. This was a concern since the MEMScap PTs would likely experience lower steady-state temperatures compared to the others. We ran two full test cycles following the MEMScap integration to verify that there were no unexpected anomalies. As expected, the MEMScap sensors experienced significantly lower temperatures at steady state, roughly 30C below the 152C target needed to adequately thermally stress the sensors. To minimize heat loss to radiation and conduction, and to increase the steady-state temperatures of the MEMScap PTs, we added aluminum and fiberglass insulation shown in Figures 8 and 9. We also installed rope heaters around the base of the bell jar. After two thermal cycle tests, we saw a favorable increase in the steady-state temperatures of the MEMScap PTs without impacting the temperatures of the others.



Figure 8. Insulation around and in between PTs.




Figure 9. Aluminum & fiberglass cover and rope heaters around base.

III. Conclusion and Future Work

As a critical component of the LAVA subsystem, important calculations will rely on the measurements the PTs output. It is vital to select a sensor that is capable of producing accurate readings while surviving high temperature cycling under vacuum. As a result, six different models of sensors were tested in three environmental conditions, RT HA, 152C HA, and 152C He, to sufficiently down select the sensor that will proceed to integrated testing in the ETU. From this trade study, we found that He does not have a significant affect in pressure readings compared to HA. Furthermore, we observed that the PTs in contact with the stainless steel manifold generally drifted less over time in comparison to the aluminum manifold.

The MEMScap sensors have successfully survived two full test cycles, but it is difficult to judge their performance this early on. With limited time remaining in the trade study, we have decided to run additional partial tests with only the 152C He pressure cycle to acquire more data points. The MEMScap sensors are significantly lighter than the other candidates in the trade study. Our goal is to gather enough data to decide whether MEMScap can be used as a strong backup option for ETU testing. Furthermore, given that there is enough time in the design cycle prior to the payload Preliminary Design Review, additional experimental changes will be made to further stress the sensors. Knowing that the sensors have successfully survived 25 full test cycles without encountering any anomalies, it will be beneficial to see how the sensors react to higher operating temperatures and longer exposure to helium.

| | Name | Range for 3psia | Range for 10psia | Range for 65 psia | Mass (g) with wiring |
|--------|---------------------------------|--------------------|---------------------|----------------------|-------------------------|
| PT-002 | Tecsis (SS) | 2.568 | 2.384 | 1.059 | 29.44 |
| PT-010 | Tecsis (Al) | 2.912 | 2.718 | 1.324 | 29.44 |
| PT-001 | Measurement Specialties (SS) | 1.637 | 1.641 | 2.127 | 42.30 |
| PT-009 | Measurement Specialties (Al) | 4.538 | 4.545 | 4.603 | 42.30 |
| PT-005 | GP 50 7900 (SS) | 17.75 | 17.19 | 18.09 | 78.92 |
| PT-013 | GP 50 7900 (Al) | 3.886 | 4.536 | 9.967 | 78.92 |
| | | | | | |
| PT-007 | GP 50 189 (SS) | 12.73 | 12.71 | 12.56 | 14.35 |

Table 9. Summary of important aspects for PT down selection, and listed by increasing mass; PT-007 is separated since it is not a contender for the FSS manifold.

Ultimately, Tecsis has proved itself to be the best sensor for ETU integration and testing. As a reiteration, GP 50 189 was tested for its potential use in the high pressure gas manifold, and due to its high pressure range, was not considered to be a contender for the FSS manifold. Measurement Specialties, a close second, drifted less over time than Tecsis, but only by a very small fraction that is not worth losing the opportunity of having a lighter unit. It is also important to note that Tecsis is the only unit to provide consistency across varying manifold materials. Over the duration of 42 thermal cycles and 25 test cycles in high temperature and helium, the Tecsis sensors experienced drift no more than 3 psia since the first test, five months ago. Overall, Tecsis has provided strong stability and consistency, and is the lightest option among its contenders. In the following months, multiple Tecsis sensors will undergo extended vacuum testing for accuracy and to identify any potential compatibility issues within the full ETU system.

Appendix

Room Temperature House Air

Data sets contain experimental trend lines, and theoretical pressures. As shown in the data sets, several tests do not have data points. This is because the affected tests did not pass the leak rate tolerance of 0.1 psia per 30 seconds due to test setup leaks, or test conductor errors.

PT-001 Measurement Specialties (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|----------------|------------------|----------------|
| 1 | 12335 | 3.2612 | 1 |
| 2 | 12334 | 2.6773 | 1 |
| 3 | - | - | - |
| 4 | 12339 | 2.5297 | 1 |
| 5 | - | - | - |
| 6 | 12337 | 2.0807 | 1 |
| 7 | 12347 | 1.3911 | 1 |
| 8 | 12335 | 1.8035 | 1 |
| 9 | 12354 | 0.7899 | 1 |
| 10 | 12343 | 1.3887 | 1 |
| 11 | 12328 | 1.2123 | 1 |
| 12 | 12527 | 1.9261 | 0.999 |
| 13 | 12348 | 2.3537 | 1 |
| 14 | - | - | - |
| 15 | 12345 | 3.7852 | 1 |
| 16 | 12356 | 4.2871 | 1 |
| 17 | 12377 | 2.0202 | 1 |
| 18 | 12375 | 2.027 | 1 |
| 19 | 12380 | 2.1683 | 1 |
| 20 | 12409 | 2.9029 | 1 |
| 21 | 12441 | 3.1912 | 1 |
| 22 | 12697 | 3.2925 | 1 |
| 23 | - | - | - |
| 24 | 12558 | 3.3968 | 1 |
| 25 | 12533 | 3.3376 | 1 |
| Factory | 12386 | - | 1 |

PT-009 Measurement Specialties (AI)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|----------------|------------------|----------------|
| 1 | 11320 | 2.7593 | 1 |
| 2 | 11318 | 1.922 | 1 |
| 3 | - | - | - |
| 4 | 11324 | 2.395 | 1 |
| 5 | - | - | - |
| 6 | 11324 | 1.8459 | 1 |
| 7 | 11338 | 1.4257 | 1 |
| 8 | 11321 | 1.7675 | 1 |
| 9 | 11340 | 0.025 | 1 |
| 10 | 11326 | 0.808 | 1 |
| 11 | 11312 | 0.4968 | 1 |
| 12 | 11496 | 1.2536 | 0.9989 |
| 13 | 11331 | 1.4839 | 1 |
| 14 | - | - | - |
| 15 | 11330 | 2.9118 | 1 |
| 16 | 11337 | 3.2829 | 1 |
| 17 | 11347 | 1.1984 | 1 |
| 18 | 11330 | 1.0582 | 1 |
| 19 | 11326 | 1.0292 | 1 |
| 20 | 11339 | 1.408 | 1 |
| 21 | 11332 | 1.5529 | 1 |
| 22 | 11354 | 1.5693 | 1 |
| 23 | - | - | - |
| 24 | 11343 | 1.5923 | 1 |
| 25 | 11346 | 1.2504 | 1 |
| Factory | 11450 | 2E-14 | 1 |

PT-002 Tectis (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 1 | 18386 | 1.8347 | 0.9998 |
| 2 | 18371 | 2.4193 | 0.9998 |
| 3 | - | - | - |
| 4 | 18378 | 2.6179 | 0.9998 |
| 5 | - | - | - |
| 6 | 18388 | 2.6127 | 0.9999 |
| 7 | 18407 | 1.8976 | 1 |
| 8 | 18349 | 3.0765 | 0.9998 |
| 9 | 18382 | 2.8405 | 0.9999 |
| 10 | 18336 | 3.133 | 0.9998 |
| 11 | 18360 | 3.0721 | 0.9999 |
| 12 | 18615 | 3.1875 | 0.999 |
| 13 | 18343 | 3.264 | 0.9999 |
| 14 | - | - | - |
| 15 | 18308 | 3.5369 | 0.9998 |
| 16 | 18324 | 3.5918 | 0.9998 |
| 17 | 18396 | 3.5943 | 0.9998 |
| 18 | 18310 | 3.6334 | 0.9997 |
| 19 | 18312 | 3.7256 | 0.9997 |
| 20 | 18333 | 3.7761 | 0.9998 |
| 21 | 18309 | 3.7833 | 0.9998 |
| 22 | 18344 | 3.8335 | 0.9998 |
| 23 | - | - | - |
| 24 | 18310 | 4.2382 | 0.9997 |
| 25 | 18315 | 4.1693 | 0.9998 |
| Factory | 18596 | -0.6283 | 1 |

PT-010 Tectis (Al)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 1 | 19030 | -0.0349 | 0.9998 |
| 2 | 19028 | 0.9182 | 0.9998 |
| 3 | - | - | - |
| 4 | 19028 | 0.7147 | 0.9998 |
| 5 | - | - | - |
| 6 | 19053 | 0.8872 | 0.9999 |
| 7 | 19079 | 0.3079 | 1 |
| 8 | 19017 | 1.3589 | 0.9998 |
| 9 | 19049 | 1.0758 | 0.9999 |
| 10 | 19005 | 1.3015 | 0.9998 |
| 11 | 19010 | 1.4374 | 0.9999 |
| 12 | 19289 | 1.2977 | 0.9989 |
| 13 | 19010 | 1.4208 | 0.9998 |
| 14 | - | - | - |
| 15 | 18988 | 1.5558 | 0.9998 |
| 16 | 19007 | 1.5349 | 0.9998 |
| 17 | 19048 | 1.6351 | 0.9998 |
| 18 | 18994 | 1.5959 | 0.9997 |
| 19 | 18996 | 1.6929 | 0.9997 |
| 20 | 19015 | 1.717 | 0.9998 |
| 21 | 18987 | 1.7657 | 0.9997 |
| 22 | 19014 | 1.7997 | 0.9998 |
| 23 | - | - | - |
| 24 | 19008 | 2.0746 | 0.9997 |
| 25 | 19012 | 2.0581 | 0.9998 |
| Factory | 19295 | -0.7445 | 1 |

PT-005 GP50 7900 (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|----------------|------------------|----------------|
| 1 | 19.933 | -3.1251 | 1 |
| 2 | 19.953 | -3.7139 | 1 |
| 3 | - | - | - |
| 4 | 19.923 | -5.8777 | 1 |
| 5 | - | - | - |
| 6 | 19.92 | -6.6878 | 1 |
| 7 | 19.963 | -8.1197 | 1 |
| 8 | 19.956 | -8.3101 | 1 |
| 9 | 19.972 | -11.18 | 1 |
| 10 | 19.969 | -11.473 | 1 |
| 11 | 19.946 | -12.391 | 1 |
| 12 | 20.207 | -12.811 | 0.9987 |
| 13 | 19.981 | -12.896 | 1 |
| 14 | - | - | - |
| 15 | 20.021 | -14.086 | 0.9999 |
| 16 | 19.986 | -14.037 | 1 |
| 17 | 19.764 | -14.162 | 0.9999 |
| 18 | 20.007 | -14.41 | 1 |
| 19 | 20.004 | -14.421 | 1 |
| 20 | 20.012 | -14.532 | 1 |
| 21 | 20.009 | -14.572 | 1 |
| 22 | 19.946 | -14.507 | 1 |
| 23 | - | - | - |
| 24 | 20.01 | -13.341 | 1 |
| 25 | 20.019 | -13.585 | 1 |
| Factory | 19.97 | -2.1024 | |

PT-013 GP50 7900 (Al)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|----------------|------------------|----------------|
| 1 | 20.163 | 0.1194 | 0.9993 |
| 2 | 20.161 | 0.0095 | 0.9994 |
| 3 | - | - | - |
| 4 | 20.105 | -0.3051 | 0.9997 |
| 5 | - | - | - |
| 6 | 20.082 | -0.4334 | 0.9997 |
| 7 | 20.064 | -0.6424 | 0.9998 |
| 8 | 20.044 | -0.7506 | 0.9999 |
| 9 | 19.957 | -1.3381 | 1 |
| 10 | 19.937 | -1.4898 | 1 |
| 11 | 19.921 | -1.4052 | 1 |
| 12 | 20.217 | -2.0944 | 0.9989 |
| 13 | 19.935 | -2.0481 | 1 |
| 14 | - | - | - |
| 15 | 19.946 | -3.2229 | 1 |
| 16 | 19.948 | -3.4356 | 1 |
| 17 | 19.886 | -3.7033 | 1 |
| 18 | 19.947 | -4.1162 | 1 |
| 19 | 19.946 | -4.185 | 1 |
| 20 | 19.953 | -4.4165 | 1 |
| 21 | 19.941 | -4.5083 | 1 |
| 22 | 19.928 | -4.5662 | 1 |
| 23 | - | - | - |
| 24 | 19.964 | -4.8458 | 1 |
| 25 | 19.975 | -4.9588 | 1 |
| Factory | 19.973 | -1.8488 | 1 |

PT-007 GP50 189 (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R² |
|----------------|---------------------------|-----------------------------|----------------------|
| 1 | 588174 | 142.89 | 0.9913 |
| 2 | 572055 | 114.62 | 1 |
| 3 | - | - | - |
| 4 | 587069 | 114.34 | 0.9973 |
| 5 | - | - | - |
| 6 | 587613 | 109.52 | 0.9977 |
| 7 | 571520 | 100.98 | 1 |
| 8 | 572966 | 102.72 | 1 |
| 9 | 573072 | 92.335 | 1 |
| 10 | 573885 | 91.378 | 1 |
| 11 | 580176 | 92.819 | 0.998 |
| 12 | 590314 | 95.676 | 0.9956 |
| 13 | 574712 | 86.522 | 1 |
| 14 | - | - | - |
| 15 | 567773 | 84.166 | 0.9981 |
| 16 | 575511 | 88.749 | 1 |
| 17 | 613129 | 82.821 | 0.9974 |
| 18 | 575918 | 143.06 | 1 |
| 19 | 574946 | 133.19 | 0.9996 |
| 20 | 576714 | 128.32 | 1 |
| 21 | 576117 | 126.72 | 1 |
| 22 | 591419 | 125.12 | 0.9962 |
| 23 | - | - | - |
| Factory | 574713 | 365.27 | 1 |

PT-003 MEMScap SP81 R (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 24 | 541.1 | 3.4167 | 0.9776 |
| 25 | 479.3 | 4.0967 | 1 |
| Factory | - | - | - |

PT-012 MEMScap RP81 R (Al)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 24 | 644.9 | -9.963 | 0.9756 |
| 25 | 562.51 | -7.5548 | 1 |
| Factory | - | - | - |

PT-007 MEMScap SP80 D (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 24 | 724.87 | -24.079 | 0.9468 |
| 25 | 566.89 | -17.063 | 1 |
| Factory | - | - | - |

PT-014 MEMScap SP80 D (Al)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 24 | 648.42 | -11.049 | 0.9721 |
| 25 | 553.7 | -8.1141 | 1 |
| Factory | - | - | - |

RT HA**Data Analysis Summary Chart for All PTs in 152C He****PT-001 Measurement Specialties (SS)**

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 369 | 3.4972 | 0.001 |
| Average | 12399.90476 | 2.467761905 | 0.999952 |
| SD | 95.57490444 | 0.895285561 | 0.000213 |
| %RSD | 0.770771278 | 36.27925203 | 0.021297 |

PT-009 Measurement Specialties (Al)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 184 | 3.2579 | 0.0011 |
| Average | 11339.71429 | 1.573147619 | 0.999948 |
| SD | 36.46021035 | 0.760256123 | 0.000234 |
| %RSD | 0.321526711 | 48.32706823 | 0.023427 |

PT-002 Tccsis (SS)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 307 | 2.4035 | 0.001 |
| Average | 18360.7619 | 3.230390476 | 0.999776 |
| SD | 65.03032608 | 0.653968375 | 0.000187 |
| %RSD | 0.354180978 | 20.24425157 | 0.018752 |

PT-010 Tccsis (Al)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 302 | 2.1095 | 0.0011 |
| Average | 19031.7619 | 1.338804762 | 0.999762 |
| SD | 61.76599832 | 0.524203732 | 0.000206 |
| %RSD | 0.324541672 | 39.15460619 | 0.020586 |

PT-005 GP50 7900 (SS)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 0.443 | 11.4469 | 0.0013 |
| Average | 19.9762381 | -11.34468095 | 0.999929 |
| SD | 0.075070066 | 3.676234974 | 0.000276 |
| %RSD | 0.37579681 | -32.40492165 | 0.027629 |

PT-013 GP50 7900 (AI)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 0.331 | 5.0782 | 0.0011 |
| Average | 20.00095238 | -2.492228571 | 0.999843 |
| SD | 0.091745235 | 1.752766445 | 0.00029 |
| %RSD | 0.458704334 | -70.32928139 | 0.029048 |

PT-007 GP50 189 (SS)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 45356 | 60.239 | 0.0087 |
| Average | 580162.2632 | 108.2076842 | 0.998484 |
| SD | 10372.46363 | 19.51804914 | 0.002212 |
| %RSD | 1.78785562 | 18.03758142 | 0.221511 |

PT-003 MEMScap SP81 R (SS)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 61.8 | 0.68 | 0.0224 |
| Average | 510.2 | 3.7567 | 0.9888 |
| SD | 30.9 | 0.34 | 0.0112 |
| %RSD | 6.056448452 | 9.050496446 | 1.132686 |

PT-012 MEMScap SP81 R (AI)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 82.39 | 2.4082 | 0.0244 |
| Average | 603.705 | -8.7589 | 0.9878 |
| SD | 41.195 | 1.2041 | 0.0122 |
| %RSD | 6.823697004 | -13.74716003 | 1.235068 |

PT-007 MEMScap SP80 D (SS)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 157.98 | 7.016 | 0.0532 |
| Average | 645.88 | -20.571 | 0.9734 |
| SD | 78.99 | 3.508 | 0.0266 |
| %RSD | 12.22982597 | -17.05313305 | 2.73269 |

PT-014 MEMScap SP80 D (Al)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 94.72 | 2.9349 | 0.0279 |
| Average | 601.06 | -9.58155 | 0.98605 |
| SD | 47.36 | 1.46745 | 0.01395 |
| %RSD | 7.879413037 | -15.31537173 | 1.414736 |

152C House Air

Data sets contain experimental trend lines, and theoretical pressures.

PT-001 Measurement Specialties (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|--------|---------|---------|
| 1 | 11754 | 1.0054 | 1 | 3.852 | 10.495 | 62.689 |
| 2 | 11761 | 0.6861 | 1 | 3.535 | 10.181 | 62.406 |
| 3 | - | - | - | - | - | - |
| 4 | 11756 | 0.569 | 1 | 3.416 | 10.060 | 62.263 |
| 5 | - | - | - | - | - | - |
| 6 | 11754 | 0.305 | 1 | 3.152 | 9.795 | 61.988 |
| 7 | 11754 | 0.168 | 1 | 3.015 | 9.658 | 61.851 |
| 8 | 11749 | -0.0045 | 1 | 2.841 | 9.481 | 61.653 |
| 9 | 11756 | -0.2215 | 1 | 2.626 | 9.270 | 61.472 |
| 10 | 11761 | 0.0605 | 1 | 2.909 | 9.556 | 61.781 |
| 11 | 11762 | 0.2506 | 1 | 3.099 | 9.747 | 61.976 |
| 12 | 11844 | 0.0368 | 0.9986 | 2.906 | 9.599 | 62.192 |
| 13 | 11754 | 0.7022 | 1 | 3.549 | 10.192 | 62.386 |
| 14 | - | - | - | - | - | - |
| 15 | 11766 | 1.2883 | 1 | 4.138 | 10.788 | 63.035 |
| 16 | 11760 | 1.441 | 1 | 4.289 | 10.936 | 63.156 |
| 17 | 11762 | 0.2303 | 1 | 3.079 | 9.727 | 61.956 |
| 18 | 11775 | 0.2551 | 1 | 3.107 | 9.762 | 62.049 |
| 19 | 11779 | 0.3861 | 1 | 3.239 | 9.896 | 62.201 |
| 20 | 11798 | 0.9698 | 1 | 3.827 | 10.495 | 62.884 |
| 21 | 11820 | 1.0932 | 1 | 3.956 | 10.636 | 63.123 |
| 22 | 11923 | 0.9158 | 1 | 3.804 | 10.542 | 63.486 |
| 23 | 11773 | 1.3711 | 1 | 4.223 | 10.876 | 63.154 |
| 24 | 11916 | 0.908 | 1 | 3.794 | 10.529 | 63.442 |
| 25 | 11921 | 1.1455 | 0.9999 | 4.033 | 10.770 | 63.705 |
| Factory | 12386 | - | 1 | - | - | - |

PT-009 Measurement Specialties (AI)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|--------|---------|---------|
| 1 | 10730 | -0.91 | 0.9999 | 1.901 | 8.461 | 60.003 |
| 2 | 10728 | -1.4949 | 0.9999 | 1.316 | 7.875 | 59.406 |
| 3 | - | - | - | - | - | - |
| 4 | 10730 | -1.3777 | 1 | 1.434 | 7.993 | 59.535 |
| 5 | - | - | - | - | - | - |
| 6 | 10727 | -1.808 | 1 | 1.003 | 7.561 | 59.088 |
| 7 | 10722 | -2.0367 | 1 | 0.773 | 7.327 | 58.831 |
| 8 | 10715 | -2.5098 | 0.9999 | 0.298 | 6.848 | 58.318 |
| 9 | 10718 | -3.1843 | 1 | -0.376 | 6.176 | 57.660 |
| 10 | 10732 | -3.0913 | 1 | -0.279 | 6.282 | 57.833 |
| 11 | 10722 | -3.053 | 1 | -0.244 | 6.311 | 57.814 |
| 12 | 10806 | -3.5312 | 0.9986 | -0.700 | 5.906 | 57.813 |
| 13 | 10717 | -3.0257 | 1 | -0.218 | 6.334 | 57.813 |
| 14 | - | - | - | - | - | - |
| 15 | 10735 | -3.031 | 0.9999 | -0.218 | 6.345 | 57.910 |
| 16 | 10739 | -3.0887 | 0.9999 | -0.275 | 6.290 | 57.875 |
| 17 | 10708 | -4.4253 | 0.9999 | -1.620 | 4.927 | 56.362 |
| 18 | 10722 | -4.8477 | 1 | -2.038 | 4.516 | 56.020 |
| 19 | 10723 | -4.9158 | 1 | -2.106 | 4.449 | 55.957 |
| 20 | 10733 | -4.8814 | 1 | -2.069 | 4.492 | 56.048 |
| 21 | 10728 | -4.9425 | 0.9999 | -2.132 | 4.427 | 55.959 |
| 22 | 10756 | -5.2766 | 1 | -2.458 | 4.117 | 55.784 |
| 23 | 10732 | -5.1817 | 0.9999 | -2.370 | 4.191 | 55.742 |
| 24 | 10735 | -5.6839 | 1 | -2.871 | 3.692 | 55.257 |
| 25 | 10736 | -5.4893 | 1 | -2.676 | 3.887 | 55.457 |
| Factory | 11450 | 2E-14 | 1 | - | - | - |

PT-002 Tesis (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R² | 3 psia | 10 psia | 65 psia |
|----------------|-----------------------|-------------------------|----------------------|---------------|----------------|----------------|
| 1 | 18666 | -1.452 | 1 | 2.190 | 9.216 | 64.423 |
| 2 | 18623 | -1.2253 | 0.9999 | 2.408 | 9.418 | 64.498 |
| 3 | - | - | - | - | - | - |
| 4 | 18585 | -0.9106 | 0.9999 | 2.716 | 9.711 | 64.679 |
| 5 | - | - | - | - | - | - |
| 6 | 18552 | -0.7156 | 0.9999 | 2.904 | 9.888 | 64.757 |
| 7 | 18527 | -0.6464 | 0.9999 | 2.968 | 9.942 | 64.738 |
| 8 | 18511 | -0.5374 | 0.9999 | 3.074 | 10.042 | 64.791 |
| 9 | 18461 | -0.455 | 0.9999 | 3.147 | 10.096 | 64.697 |
| 10 | 18456 | -0.3117 | 0.9999 | 3.289 | 10.237 | 64.823 |
| 11 | 18433 | -0.1613 | 0.9999 | 3.435 | 10.374 | 64.892 |
| 12 | 18552 | -0.5824 | 0.9986 | 3.037 | 10.021 | 64.891 |
| 13 | 18386 | -0.088 | 0.9999 | 3.499 | 10.420 | 64.799 |
| 14 | - | - | - | - | - | - |
| 15 | 18353 | 0.1496 | 0.9999 | 3.730 | 10.639 | 64.920 |
| 16 | 18338 | 0.2304 | 0.9999 | 3.808 | 10.711 | 64.948 |
| 17 | 18327 | 0.3098 | 0.9999 | 3.886 | 10.784 | 64.989 |
| 18 | 18270 | 0.4439 | 0.9999 | 4.009 | 10.886 | 64.922 |
| 19 | 18278 | 0.5274 | 0.9999 | 4.094 | 10.974 | 65.033 |
| 20 | 18280 | 0.6056 | 0.9999 | 4.172 | 11.053 | 65.119 |
| 21 | 18250 | 0.6941 | 0.9999 | 4.255 | 11.125 | 65.101 |
| 22 | 18305 | 0.4742 | 1 | 4.046 | 10.936 | 65.076 |
| 23 | 18224 | 0.7409 | 0.9998 | 4.297 | 11.157 | 65.056 |
| 24 | 18228 | 0.9174 | 0.9999 | 4.474 | 11.335 | 65.247 |
| 25 | 18219 | 1.2789 | 0.9999 | 4.834 | 11.692 | 65.577 |
| Factory | 18596 | -0.6283 | 1 | - | - | - |

PT-010 Tectis (AI)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|--------|---------|---------|
| 1 | 19374 | -0.7467 | 1 | 3.013 | 10.041 | 65.264 |
| 2 | 19342 | -0.5413 | 1 | 3.212 | 10.229 | 65.360 |
| 3 | - | - | - | - | - | - |
| 4 | 19295 | -0.2108 | 1 | 3.534 | 10.533 | 65.530 |
| 5 | - | - | - | - | - | - |
| 6 | 19260 | 0.0039 | 1 | 3.741 | 10.728 | 65.626 |
| 7 | 19238 | 0.0785 | 1 | 3.812 | 10.791 | 65.625 |
| 8 | 19219 | 0.2144 | 1 | 3.944 | 10.916 | 65.697 |
| 9 | 19178 | 0.2999 | 1 | 4.022 | 10.979 | 65.642 |
| 10 | 19152 | 0.4827 | 1 | 4.199 | 11.147 | 65.737 |
| 11 | 19141 | 0.5985 | 1 | 4.313 | 11.257 | 65.815 |
| 12 | 19256 | 0.2196 | 0.9987 | 3.956 | 10.942 | 65.828 |
| 13 | 19090 | 0.7491 | 1 | 4.454 | 11.379 | 65.792 |
| 14 | - | - | - | - | - | - |
| 15 | 19046 | 0.9755 | 1 | 4.671 | 11.581 | 65.868 |
| 16 | 19029 | 1.0862 | 1 | 4.779 | 11.682 | 65.921 |
| 17 | 19017 | 1.24 | 0.9999 | 4.930 | 11.829 | 66.034 |
| 18 | 18961 | 1.4212 | 1 | 5.101 | 11.979 | 66.024 |
| 19 | 18960 | 1.5128 | 1 | 5.192 | 12.070 | 66.112 |
| 20 | 18943 | 1.599 | 0.9999 | 5.275 | 12.147 | 66.141 |
| 21 | 18917 | 1.7378 | 0.9999 | 5.409 | 12.271 | 66.191 |
| 22 | 18949 | 1.671 | 1 | 5.348 | 12.222 | 66.233 |
| 23 | 18882 | 1.8514 | 0.9999 | 5.516 | 12.365 | 66.185 |
| 24 | 18897 | 2.0522 | 0.9999 | 5.719 | 12.575 | 66.437 |
| 25 | 18882 | 2.3629 | 0.9999 | 6.027 | 12.877 | 66.697 |
| Factory | 19295 | -0.7445 | 1 | - | - | - |

PT-005 GP50 7900 (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|---------|---------|---------|
| 1 | 20.049 | -3.181 | 1 | 1.942 | 8.969 | 64.187 |
| 2 | 20.026 | -3.9164 | 1 | 1.200 | 8.220 | 63.374 |
| 3 | - | - | - | - | - | - |
| 4 | 20.046 | -7.0055 | 1 | -1.884 | 5.143 | 60.352 |
| 5 | - | - | - | - | - | - |
| 6 | 20.043 | -8.092 | 1 | -2.971 | 4.055 | 59.256 |
| 7 | 19.994 | -9.9613 | 1 | -4.853 | 2.156 | 57.222 |
| 8 | 19.995 | -10.318 | 1 | -5.209 | 1.800 | 56.868 |
| 9 | 19.926 | -14.263 | 0.9999 | -9.172 | -2.187 | 52.692 |
| 10 | 20.049 | -14.873 | 1 | -9.750 | -2.723 | 52.495 |
| 11 | 19.971 | -15.964 | 1 | -10.861 | -3.861 | 51.142 |
| 12 | 20.193 | -16.992 | 0.9988 | -11.833 | -4.754 | 50.860 |
| 13 | 19.968 | -16.89 | 1 | -11.788 | -4.789 | 50.206 |
| 14 | - | - | - | - | - | - |
| 15 | 20.049 | -18.995 | 1 | -13.872 | -6.845 | 48.373 |
| 16 | 20.049 | -19.264 | 1 | -14.141 | -7.114 | 48.104 |
| 17 | 19.841 | -19.636 | 0.9998 | -14.567 | -7.612 | 47.033 |
| 18 | 20.049 | -20.181 | 1 | -15.058 | -8.031 | 47.187 |
| 19 | 20.047 | -20.273 | 1 | -15.151 | -8.124 | 47.088 |
| 20 | 20.051 | -20.543 | 1 | -15.420 | -8.392 | 46.832 |
| 21 | 20.029 | -20.757 | 0.9998 | -15.640 | -8.619 | 46.544 |
| 22 | 20.052 | -20.801 | 1 | -15.678 | -8.649 | 46.577 |
| 23 | 20.047 | -20.992 | 1 | -15.870 | -8.843 | 46.369 |
| 24 | 20.042 | -19.584 | 1 | -14.463 | -7.438 | 47.760 |
| 25 | 20.045 | -19.855 | 1 | -14.733 | -7.707 | 47.499 |
| Factory | 19.97 | -2.1024 | 1 | - | - | - |

PT-013 GP50 7900 (AI)

| Test# | Slope (psia/V) | Intercept (psia) | R² | 3 psia | 10 psia | 65 psia |
|----------------|-----------------------|-------------------------|----------------------|---------------|----------------|----------------|
| 1 | 21.899 | 4.1443 | 0.9838 | 9.461 | 17.136 | 77.439 |
| 2 | 21.913 | 4.1876 | 0.9825 | 9.507 | 17.187 | 77.529 |
| 3 | - | - | - | - | - | - |
| 4 | 21.723 | 4.087 | 0.9848 | 9.361 | 16.974 | 76.793 |
| 5 | - | - | - | - | - | - |
| 6 | 21.748 | 3.9404 | 0.9839 | 9.220 | 16.842 | 76.730 |
| 7 | 21.627 | 3.8488 | 0.9858 | 9.099 | 16.679 | 76.233 |
| 8 | 21.547 | 3.9392 | 0.9863 | 9.170 | 16.722 | 76.056 |
| 9 | 21.269 | 3.4789 | 0.9898 | 8.642 | 16.097 | 74.665 |
| 10 | 21.251 | 3.4166 | 0.9889 | 8.576 | 16.024 | 74.543 |
| 11 | 21.215 | 3.096 | 0.9905 | 8.246 | 15.682 | 74.102 |
| 12 | 21.276 | 2.7859 | 0.9865 | 7.951 | 15.408 | 73.996 |
| 13 | 21.007 | 3.0733 | 0.9921 | 8.173 | 15.536 | 73.383 |
| 14 | - | - | - | - | - | - |
| 15 | 20.677 | 2.5152 | 0.9943 | 7.535 | 14.782 | 71.720 |
| 16 | 20.55 | 2.4253 | 0.9949 | 7.414 | 14.616 | 71.205 |
| 17 | 20.486 | 2.0419 | 0.9959 | 7.015 | 14.195 | 70.608 |
| 18 | 20.362 | 1.66 | 0.997 | 6.603 | 13.740 | 69.811 |
| 19 | 20.338 | 1.5528 | 0.9972 | 6.490 | 13.618 | 69.623 |
| 20 | 20.25 | 1.3209 | 1 | 6.237 | 13.334 | 69.097 |
| 21 | 20.167 | 1.3114 | 0.998 | 6.207 | 13.275 | 68.810 |
| 22 | 20.222 | 0.9966 | 0.9982 | 5.906 | 12.993 | 68.679 |
| 23 | 20.129 | 0.699 | 0.9986 | 5.586 | 12.640 | 68.070 |
| 24 | 20.068 | 0.8174 | 0.9987 | 5.689 | 12.723 | 67.984 |
| 25 | 20.045 | 0.6745 | 0.9988 | 5.541 | 12.566 | 67.764 |
| Factory | 19.973 | -1.8488 | 1 | - | - | - |

PT-007 GP50 189 (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|----------|----------|----------|
| 1 | 559885 | -84.687 | 0.9995 | -437.610 | -430.791 | -377.210 |
| 2 | 546906 | -81.663 | 0.9982 | -426.405 | -419.744 | -367.405 |
| 3 | - | - | - | - | - | - |
| 4 | 559984 | -85.981 | 0.9999 | -438.967 | -432.146 | -378.556 |
| 5 | - | - | - | - | - | - |
| 6 | 560992 | -88.215 | 0.9997 | -441.836 | -435.003 | -381.316 |
| 7 | 548518 | -86.999 | 0.998 | -432.757 | -426.076 | -373.583 |
| 8 | 547722 | -87.748 | 0.9979 | -433.004 | -426.333 | -373.916 |
| 9 | 538952 | -88.78 | 0.9967 | -428.508 | -421.944 | -370.366 |
| 10 | 561088 | -93.7 | 0.9998 | -447.381 | -440.547 | -386.851 |
| 11 | 547968 | -91.042 | 0.9979 | -436.453 | -429.779 | -377.339 |
| 12 | 567119 | -96.774 | 0.9986 | -454.257 | -447.350 | -393.076 |
| 13 | 549701 | -92.555 | 0.9978 | -439.059 | -432.363 | -379.757 |
| 14 | - | - | - | - | - | - |
| 15 | 563862 | -96.108 | 0.9997 | -451.538 | -444.670 | -390.709 |
| 16 | 562253 | -95.999 | 0.9997 | -450.415 | -443.567 | -389.759 |
| 17 | 532768 | -92.51 | 0.9953 | -428.340 | -421.851 | -370.865 |
| 18 | 553626 | -94.353 | 0.9982 | -443.331 | -436.588 | -383.606 |
| 19 | 555837 | -95.59 | 0.9992 | -445.962 | -439.191 | -385.998 |
| 20 | 564662 | -99.998 | 0.9999 | -455.932 | -449.055 | -395.017 |
| 21 | 560007 | -102.59 | 0.9973 | -455.590 | -448.769 | -395.177 |
| 22 | 560705 | -102.92 | 0.9999 | -456.360 | -449.531 | -395.871 |
| 23 | 563951 | -113.65 | 0.9999 | -469.136 | -462.267 | -408.297 |
| Factory | 574713 | 365.27 | 1 | - | - | - |

PT-003 MEMScap SP81 R (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|----------------|------------------|----------------|
| 24 | 570.17 | 3.781 | 1 |
| 25 | 574.38 | 3.804 | 1 |
| Factory | - | - | - |

PT-012 MEMScap SP81 R (Al)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|----------------|------------------|----------------|
| 24 | 668.71 | -8.8979 | 1 |
| 25 | 671.9 | -8.9196 | 1 |
| Factory | - | - | - |

PT-007 MEMScap SP80 D (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|----------------|------------------|----------------|
| 24 | 676.59 | -21.121 | 1 |
| 25 | 684.7 | -21.413 | 1 |
| Factory | - | - | - |

PT-014 MEMScap SP80 D (Al)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|----------------|------------------|----------------|
| 24 | 661.76 | -9.6475 | 1 |
| 25 | 668.93 | -9.7188 | 1 |
| Factory | - | - | - |

Data Analysis Summary Chart for All PTs in 152C HA**PT-001 Measurement Specialties (SS)**

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|-----------|----------|----------|
| Range | 174 | 1.6625 | 0.0014 | 1.6634688 | 1.665729 | 2.232897 |
| Average | 11790.81818 | 0.616445455 | 0.999932 | 1.663 | 10.13592 | 62.49301 |
| SD | 56.05568365 | 0.484799264 | 0.000291 | 0.4892145 | 0.500798 | 0.640898 |
| %RSD | 0.475418099 | 78.64430829 | 0.029139 | 29.409295 | 4.940829 | 1.025552 |

PT-009 Measurement Specialties (AI)

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|-----------|----------|----------|
| Range | 98 | 4.7739 | 0.0014 | 4.77259 | 4.769533 | 4.745516 |
| Average | 10731.54545 | -3.53575 | 0.9999 | 4.305 | 5.836779 | 57.38569 |
| SD | 18.90581265 | 1.440453528 | 0.000288 | 1.4398328 | 1.43845 | 1.430789 |
| %RSD | 0.176170457 | -40.73968826 | 0.028765 | 33.446449 | 24.64458 | 2.493286 |

PT-002 Tccsis (SS)

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|-----------|----------|----------|
| Range | 447 | 2.7309 | 0.0014 | 2.643685 | 2.475423 | 1.153365 |
| Average | 18401.09091 | -0.032431818 | 0.999845 | 2.425 | 10.48447 | 64.908 |
| SD | 138.1527182 | 0.708960048 | 0.000274 | 0.6824182 | 0.631311 | 0.243348 |
| %RSD | 0.750785477 | -2186.001549 | 0.027428 | 28.136607 | 6.021387 | 0.374912 |

PT-010 Tccsis (AI)

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|-----------|----------|----------|
| Range | 492 | 3.1096 | 0.0013 | 3.0141246 | 2.835642 | 1.433279 |
| Average | 19092.18182 | 0.848081818 | 0.999914 | 2.815 | 11.47909 | 65.89814 |
| SD | 155.9418995 | 0.852355603 | 0.000268 | 0.8224309 | 0.76656 | 0.335837 |
| %RSD | 0.816784069 | 100.5039355 | 0.026851 | 29.216698 | 6.677883 | 0.50963 |

PT-005 GP50 7900 (SS) 152C HA

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|-----------|----------|----------|
| Range | 0.352 | 17.811 | 0.0012 | 17.811511 | 17.81221 | 17.81772 |
| Average | 20.0255 | -15.56078182 | 0.999923 | 17.070 | -3.42475 | 51.72811 |
| SD | 0.062749683 | 5.688411255 | 0.000252 | 5.688098 | 5.687742 | 5.687903 |
| %RSD | 0.313348896 | -36.55607618 | 0.025216 | 33.321734 | -166.078 | 10.99577 |

PT-013 GP50 7900 (Al) 152C HA

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|-----------|----------|----------|
| Range | 1.868 | 3.5131 | 0.0175 | 3.9665901 | 4.621274 | 9.765218 |
| Average | 20.89859091 | 2.546045455 | 0.992114 | 3.967 | 14.94394 | 72.49276 |
| SD | 0.648956691 | 1.221807283 | 0.005826 | 1.3760816 | 1.599926 | 3.37548 |
| %RSD | 3.105265298 | 47.98843168 | 0.58719 | 34.691802 | 10.70618 | 4.656299 |

PT-007 GP50 189 (SS) 152C HA

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|-----------|----------|----------|
| Range | 34351 | 31.987 | 0.0046 | 29.527484 | 29.31122 | 27.77187 |
| Average | 555325.3 | -93.5931 | 0.998655 | -441.5192 | -434.765 | -381.695 |
| SD | 9002.98079 | 7.266811611 | 0.001254 | 9.366593 | 9.271707 | 8.540104 |
| %RSD | 1.621208468 | -7.764259984 | 0.125527 | -2.121446 | -2.13258 | -2.23742 |

PT-003 MEMScap SP81 R (SS)

| | Slope (psia/V) | Intercept (psia) | R ² |
|----------------|----------------|------------------|----------------|
| Range | 4.21 | 0.023 | 0 |
| Average | 572.275 | 3.7925 | 1 |
| SD | 2.105 | 0.0115 | 0 |
| %RSD | 0.367830152 | 0.303230059 | 0 |

PT-012 MEMScap SP81 R (Al)

| | Slope (psia/V) | Intercept (psia) | R ² |
|----------------|----------------|------------------|----------------|
| Range | 3.19 | 0.0217 | 0 |
| Average | 670.305 | -8.90875 | 1 |
| SD | 1.595 | 0.01085 | 0 |
| %RSD | 0.23795138 | -0.121790375 | 0 |

PT-007 MEMScap SP80 D (SS)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 8.11 | 0.292 | 0 |
| Average | 680.645 | -21.267 | 1 |
| SD | 4.055 | 0.146 | 0 |
| %RSD | 0.595758435 | -0.686509616 | 0 |

PT-014 MEMScap SP80 D (Al)

| | Slope (psia/V) | Intercept (psia) | R² |
|----------------|-----------------------|-------------------------|----------------------|
| Range | 7.17 | 0.0713 | 0 |
| Average | 665.345 | -9.68315 | 1 |
| SD | 3.585 | 0.03565 | 0 |
| %RSD | 0.538818207 | -0.368165318 | 0 |

152C Helium

Data sets contain experimental trend lines, and theoretical pressures.

PT-001 Measurement Specialties (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|--------|---------|---------|
| 1 | 11772 | 0.6791 | 1 | 3.530 | 10.183 | 62.457 |
| 2 | 11820 | 0.2544 | 0.9996 | 3.117 | 9.797 | 62.284 |
| 3 | - | - | - | - | - | - |
| 4 | 11768 | 0.3496 | 1 | 3.200 | 9.851 | 62.106 |
| 5 | - | - | - | - | - | - |
| 6 | 11764 | 0.0643 | 1 | 2.914 | 9.562 | 61.800 |
| 7 | 11761 | -0.0414 | 1 | 2.807 | 9.454 | 61.679 |
| 8 | 11761 | -0.2843 | 1 | 2.564 | 9.211 | 61.436 |
| 9 | 11773 | -0.4704 | 1 | 2.381 | 9.035 | 61.313 |
| 10 | 11769 | -0.1253 | 1 | 2.725 | 9.377 | 61.637 |
| 11 | 11769 | 0.0647 | 1 | 2.915 | 9.567 | 61.827 |
| 12 | 11765 | 0.2504 | 1 | 3.100 | 9.749 | 61.991 |
| 13 | 11770 | 0.5007 | 1 | 3.351 | 10.003 | 62.268 |
| 14 | - | - | - | - | - | - |
| 15 | 11775 | 1.0364 | 1 | 3.888 | 10.543 | 62.830 |
| 16 | 11772 | 1.1477 | 1 | 3.999 | 10.652 | 62.926 |
| 17 | 11762 | 0.0535 | 1 | 2.902 | 9.550 | 61.779 |
| 18 | 11789 | 0.0797 | 1 | 2.935 | 9.598 | 61.947 |
| 19 | 11790 | 0.2291 | 1 | 3.085 | 9.748 | 62.101 |
| 20 | 11806 | 0.7983 | 1 | 3.658 | 10.330 | 62.755 |
| 21 | 11830 | 0.8718 | 1 | 3.737 | 10.423 | 62.954 |
| 22 | 11885 | 0.9048 | 1 | 3.783 | 10.500 | 63.276 |
| 23 | 11781 | 1.165 | 1 | 4.018 | 10.677 | 62.990 |
| 24 | 11942 | 0.7318 | 1 | 3.624 | 10.373 | 63.402 |
| 25 | 11883 | 1.0795 | 1 | 3.958 | 10.673 | 63.440 |
| Factory | 12386 | - | 1 | 3 | 10 | 65 |

PT-009 Measurement Specialties (AI)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|--------|---------|---------|
| 1 | 10749 | -1.399 | 1 | 1.417 | 7.989 | 59.622 |
| 2 | 10793 | -2.0008 | 0.9996 | 0.827 | 7.425 | 59.270 |
| 3 | - | - | - | - | - | - |
| 4 | 10745 | -1.6715 | 1 | 1.144 | 7.713 | 59.326 |
| 5 | - | - | - | - | - | - |
| 6 | 10740 | -2.0769 | 1 | 0.737 | 7.303 | 58.893 |
| 7 | 10739 | -2.3174 | 1 | 0.496 | 7.062 | 58.646 |
| 8 | 10736 | -2.9315 | 1 | -0.119 | 6.445 | 58.015 |
| 9 | 10747 | -3.5202 | 1 | -0.704 | 5.866 | 57.489 |
| 10 | 10743 | -3.3458 | 1 | -0.531 | 6.037 | 57.641 |
| 11 | 10741 | -3.3224 | 1 | -0.508 | 6.058 | 57.653 |
| 12 | 10737 | -3.3689 | 1 | -0.556 | 6.008 | 57.584 |
| 13 | 10745 | -3.3144 | 1 | -0.499 | 6.070 | 57.683 |
| 14 | - | - | - | - | - | - |
| 15 | 10739 | -3.3616 | 1 | -0.548 | 6.017 | 57.602 |
| 16 | 10745 | -3.4123 | 1 | -0.597 | 5.972 | 57.586 |
| 17 | 10729 | -4.6614 | 1 | -1.850 | 4.709 | 56.246 |
| 18 | 10726 | -5.0777 | 1 | -2.267 | 4.290 | 55.812 |
| 19 | 10726 | -5.1372 | 1 | -2.327 | 4.230 | 55.753 |
| 20 | 10731 | -5.0756 | 1 | -2.264 | 4.296 | 55.843 |
| 21 | 10748 | -5.1911 | 1 | -2.375 | 4.196 | 55.824 |
| 22 | 10746 | -5.3144 | 1 | -2.499 | 4.071 | 55.689 |
| 23 | 10734 | -5.4192 | 1 | -2.607 | 3.955 | 55.516 |
| 24 | 10737 | -5.9344 | 1 | -3.121 | 3.443 | 55.018 |
| 25 | 10736 | -5.6693 | 1 | -2.856 | 3.707 | 55.277 |
| Factory | 11450 | 2E-14 | 1 | 3 | 10 | 65 |

PT-002 Tectis (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|--------|---------|---------|
| 1 | 18726 | -1.5833 | 1 | 2.070 | 9.119 | 64.504 |
| 2 | 18781 | -1.662 | 0.9996 | 2.002 | 9.072 | 64.619 |
| 3 | - | - | - | - | - | - |
| 4 | 18651 | -1.1335 | 1 | 2.506 | 9.526 | 64.689 |
| 5 | - | - | - | - | - | - |
| 6 | 18610 | -0.924 | 1 | 2.707 | 9.712 | 64.754 |
| 7 | 18591 | -0.8558 | 1 | 2.772 | 9.770 | 64.755 |
| 8 | 18571 | -0.743 | 1 | 2.880 | 9.871 | 64.797 |
| 9 | 18535 | -0.6658 | 1 | 2.951 | 9.928 | 64.747 |
| 10 | 18521 | -0.5717 | 1 | 3.042 | 10.014 | 64.792 |
| 11 | 18502 | -0.4146 | 1 | 3.195 | 10.160 | 64.882 |
| 12 | 18483 | -0.4228 | 1 | 3.183 | 10.141 | 64.807 |
| 13 | 18463 | -0.3546 | 1 | 3.248 | 10.198 | 64.804 |
| 14 | - | - | - | - | - | - |
| 15 | 18420 | -0.0975 | 1 | 3.496 | 10.430 | 64.910 |
| 16 | 18405 | -0.0342 | 1 | 3.557 | 10.485 | 64.920 |
| 17 | 18382 | 0.0852 | 1 | 3.672 | 10.591 | 64.958 |
| 18 | 18353 | 0.1966 | 1 | 3.777 | 10.686 | 64.967 |
| 19 | 18358 | 0.282 | 0.9999 | 3.864 | 10.774 | 65.070 |
| 20 | 18336 | 0.3873 | 0.9999 | 3.965 | 10.867 | 65.098 |
| 21 | 18332 | 0.4232 | 1 | 4.000 | 10.901 | 65.120 |
| 22 | 18322 | 0.4806 | 1 | 4.055 | 10.952 | 65.142 |
| 23 | 18294 | 0.5047 | 0.9999 | 4.074 | 10.960 | 65.067 |
| 24 | 18305 | 0.6569 | 0.9999 | 4.228 | 11.119 | 65.258 |
| 25 | 18294 | 1.0012 | 1 | 4.571 | 11.457 | 65.564 |
| Factory | 18596 | -0.6283 | 1 | 3 | 10 | 65 |

PT-010 Tectis (AI)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|--------|---------|---------|
| 1 | 19403 | -0.7102 | 1 | 3.055 | 10.094 | 65.399 |
| 2 | 19464 | -0.787 | 0.9996 | 2.990 | 10.051 | 65.530 |
| 3 | - | - | - | - | - | - |
| 4 | 19326 | -0.2553 | 1 | 3.495 | 10.506 | 65.591 |
| 5 | - | - | - | - | - | - |
| 6 | 19284 | -0.0275 | | 3.715 | 10.710 | 65.676 |
| 7 | 19264 | 0.0452 | 1 | 3.783 | 10.772 | 65.681 |
| 8 | 19244 | 0.1757 | 1 | 3.910 | 10.891 | 65.743 |
| 9 | 19205 | 0.298 | 1 | 4.025 | 10.992 | 65.732 |
| 10 | 19194 | 0.3681 | 1 | 4.093 | 11.056 | 65.765 |
| 11 | 19169 | 0.5184 | 1 | 4.238 | 11.192 | 65.830 |
| 12 | 19150 | 0.5534 | 1 | 4.270 | 11.217 | 65.800 |
| 13 | 19122 | 0.655 | 1 | 4.366 | 11.303 | 65.807 |
| 14 | - | - | - | - | - | - |
| 15 | 19079 | 0.8937 | 1 | 4.596 | 11.517 | 65.899 |
| 16 | 19060 | 0.9876 | 1 | 4.686 | 11.601 | 65.928 |
| 17 | 19030 | 1.1747 | 1 | 4.868 | 11.771 | 66.013 |
| 18 | 18999 | 1.3555 | 1 | 5.042 | 11.935 | 66.088 |
| 19 | 19001 | 1.4484 | 1 | 5.136 | 12.029 | 66.188 |
| 20 | 18976 | 1.5099 | 1 | 5.192 | 12.076 | 66.164 |
| 21 | 18968 | 1.6114 | 1 | 5.292 | 12.173 | 66.238 |
| 22 | 18949 | 1.671 | 1 | 5.348 | 12.222 | 66.233 |
| 23 | 18921 | 1.7458 | 1 | 5.418 | 12.281 | 66.213 |
| 24 | 18939 | 1.9607 | 1 | 5.636 | 12.506 | 66.489 |
| 25 | 18929 | 2.2288 | 1 | 5.902 | 12.769 | 66.723 |
| Factory | 19295 | -0.7445 | 1 | 3 | 10 | 65 |

PT-005 GP50 7900 (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|---------|---------|---------|
| 1 | 20.033 | -3.1475 | 1 | 1.971 | 8.993 | 64.167 |
| 2 | 20.12 | -4.1613 | 0.9996 | 0.979 | 8.032 | 63.445 |
| 3 | - | - | - | - | - | - |
| 4 | 20.032 | -6.9796 | 1 | -1.861 | 5.160 | 60.331 |
| 5 | - | - | - | - | - | - |
| 6 | 20.031 | -8.0741 | 1 | -2.956 | 4.065 | 59.233 |
| 7 | 20.033 | -9.9941 | 1 | -4.876 | 2.146 | 57.320 |
| 8 | 20.035 | -10.369 | 1 | -5.250 | 1.773 | 56.952 |
| 9 | 20.039 | -14.4 | 1 | -9.280 | -2.256 | 52.934 |
| 10 | 20.038 | -14.881 | 1 | -9.761 | -2.737 | 52.450 |
| 11 | 20.039 | -16.066 | 1 | -10.946 | -3.922 | 51.268 |
| 12 | 20.05 | -16.491 | 1 | -11.368 | -4.340 | 50.880 |
| 13 | 20.045 | -17.04 | 1 | -11.918 | -4.892 | 50.314 |
| 14 | - | - | - | - | - | - |
| 15 | 19.991 | -19.047 | 0.9999 | -13.939 | -6.932 | 48.126 |
| 16 | 20.049 | -19.319 | 1 | -14.196 | -7.169 | 48.049 |
| 17 | 19.972 | -19.851 | 0.9999 | -14.748 | -7.747 | 47.258 |
| 18 | 19.931 | -20.067 | 1 | -14.975 | -7.988 | 46.904 |
| 19 | 19.938 | -20.194 | 0.9999 | -15.100 | -8.111 | 46.801 |
| 20 | 19.93 | -20.397 | 0.9999 | -15.305 | -8.319 | 46.571 |
| 21 | 19.935 | -20.618 | 0.9999 | -15.525 | -8.537 | 46.367 |
| 22 | 19.933 | -20.673 | 0.9999 | -15.580 | -8.593 | 46.305 |
| 23 | 19.925 | -20.871 | 0.9999 | -15.780 | -8.796 | 46.080 |
| 24 | 19.925 | -19.503 | 0.9999 | -14.412 | -7.428 | 47.448 |
| 25 | 19.937 | -19.75 | 0.9999 | -14.656 | -7.668 | 47.242 |
| Factory | 19.97 | -2.1024 | 1 | 3 | 10 | 65 |

PT-013 GP50 7900 (AI)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|--------|---------|---------|
| 1 | 22.042 | 4.0541 | 0.9821 | 9.405 | 17.130 | 77.828 |
| 2 | 21.971 | 4.1482 | 0.9785 | 9.482 | 17.182 | 77.684 |
| 3 | - | - | - | - | - | - |
| 4 | 21.817 | 4.1519 | 0.9818 | 9.448 | 17.095 | 77.172 |
| 5 | - | - | - | - | - | - |
| 6 | 21.736 | 4.0937 | 0.9837 | 9.370 | 16.988 | 76.843 |
| 7 | 21.655 | 3.8805 | 0.9846 | 9.138 | 16.727 | 76.359 |
| 8 | 21.551 | 4.009 | 0.9852 | 9.241 | 16.794 | 76.139 |
| 9 | 21.334 | 3.4267 | 0.9886 | 8.606 | 16.083 | 74.831 |
| 10 | 21.329 | 3.3074 | 0.9886 | 8.485 | 15.961 | 74.695 |
| 11 | 21.215 | 3.1653 | 0.9901 | 8.316 | 15.751 | 74.171 |
| 12 | 21.151 | 3.1665 | 0.9906 | 8.301 | 15.714 | 73.958 |
| 13 | 21.069 | 3.0915 | 0.9909 | 8.206 | 15.590 | 73.609 |
| 14 | - | - | - | - | - | - |
| 15 | 20.745 | 2.4183 | 0.9942 | 7.455 | 14.725 | 71.851 |
| 16 | 20.624 | 2.2861 | 0.9947 | 7.293 | 14.521 | 71.314 |
| 17 | 20.416 | 2.2069 | 0.9961 | 7.163 | 14.319 | 70.538 |
| 18 | 20.363 | 1.8 | 0.9967 | 6.743 | 13.880 | 69.954 |
| 19 | 20.361 | 1.5764 | 0.9971 | 6.519 | 13.655 | 69.724 |
| 20 | 20.272 | 1.3591 | 0.9977 | 6.280 | 13.385 | 69.209 |
| 21 | 20.265 | 1.119 | 0.9979 | 6.039 | 13.141 | 68.945 |
| 22 | 20.216 | 1.0375 | 0.9982 | 5.945 | 13.030 | 68.700 |
| 23 | 20.145 | 0.7052 | 0.9986 | 5.596 | 12.656 | 68.130 |
| 24 | 20.138 | 0.7455 | 0.9986 | 5.634 | 12.692 | 68.147 |
| 25 | 20.051 | 0.7511 | 0.9987 | 5.619 | 12.646 | 67.861 |
| Factory | 19.973 | -1.8488 | 1 | 3 | 10 | 65 |

PT-007 GP50 189 (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|---------|----------------|------------------|----------------|----------|----------|----------|
| 1 | 559352 | -83.421 | 0.9996 | -436.008 | -429.195 | -375.665 |
| 2 | 561875 | -83.786 | 0.9994 | -437.964 | -431.120 | -377.349 |
| 3 | - | - | - | - | - | - |
| 4 | 559666 | -85.553 | 0.9998 | -438.338 | -431.521 | -377.961 |
| 5 | - | - | - | - | - | - |
| 6 | 559920 | -87.566 | 0.9997 | -440.511 | -433.691 | -380.107 |
| 7 | 560566 | -88.923 | 0.9998 | -442.275 | -435.448 | -381.802 |
| 8 | 561272 | -89.858 | 0.9996 | -443.655 | -436.819 | -383.105 |
| 9 | 562138 | -92.441 | 0.9999 | -446.784 | -439.938 | -386.141 |
| 10 | 561601 | -93.162 | 0.9997 | -447.167 | -440.327 | -386.581 |
| 11 | 561550 | -92.997 | 0.9998 | -446.970 | -440.130 | -386.390 |
| 12 | 561570 | -94.75 | 0.9997 | -448.735 | -441.895 | -388.153 |
| 13 | 561622 | -94.368 | 0.9998 | -448.386 | -441.546 | -387.798 |
| 14 | - | - | - | - | - | - |
| 15 | 551001 | -93.458 | 0.9944 | -440.781 | -434.070 | -381.339 |
| 16 | 560923 | -95.162 | 0.9998 | -448.739 | -441.907 | -388.227 |
| 17 | 549913 | -95.301 | 0.9976 | -441.938 | -435.240 | -382.614 |
| 18 | 544853 | -93.903 | 0.9977 | -437.351 | -430.714 | -378.572 |
| 19 | 546796 | -94.531 | 0.9977 | -439.204 | -432.544 | -380.215 |
| 20 | 546856 | -96.358 | 0.9976 | -441.068 | -434.408 | -382.074 |
| 21 | 546189 | -98.911 | 0.9975 | -443.201 | -436.548 | -384.278 |
| 22 | 547330 | -100.09 | 0.9973 | -445.099 | -438.433 | -386.053 |
| 23 | 545581 | -109.22 | 0.9968 | -453.127 | -446.481 | -394.269 |
| Factory | 574713 | 365.27 | 1 | 3 | 10 | 65 |

PT-003 MEMScap SP81 R (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 24 | 572.11 | 3.7637 | 1 |
| 25 | 575.75 | 3.789 | 1 |
| Factory | - | - | - |

PT-012 MEMScap SP81 R (Al)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 24 | 669.14 | -8.8701 | 1 |
| 25 | 671.52 | -8.8878 | 1 |
| Factory | - | - | - |

PT-007 MEMScap SP80 D (SS)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 24 | 674.06 | -20.971 | 0.9999 |
| 25 | 681.93 | -21.256 | 0.9999 |
| Factory | - | - | - |

PT-014 MEMScap SP80 D (Al)

| Test# | Slope (psia/V) | Intercept (psia) | R ² |
|---------|-------------------|---------------------|----------------|
| 24 | 661.79 | -9.6117 | 1 |
| 25 | 668.08 | -9.676 | 1 |
| Factory | - | - | - |

Data Analysis Summary Chart for All PTs in 152C He**PT-001 Measurement Specialties (SS) 152C He**

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|----------|-------------|-------------|
| Range | 181 | 1.6354 | 0.0004 | 1.637338 | 1.641858905 | 2.127164654 |
| Average | 11795.77273 | 0.424518182 | 0.999982 | 1.637 | 9.947990431 | 62.3270878 |
| SD | 47.47145728 | 0.479190046 | 8.33E-05 | 0.484617 | 0.498082082 | 0.634148931 |
| %RSD | 0.402444659 | 112.8785684 | 0.008332 | 29.59785 | 5.006861294 | 1.017453171 |

PT-009 Measurement Specialties (AI) 152C He

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|----------|-------------|-------------|
| Range | 67 | 4.5354 | 0.0004 | 4.538544 | 4.545880349 | 4.603522271 |
| Average | 10741.45455 | -3.7965 | 0.999982 | 4.265 | 5.584683009 | 57.18118956 |
| SD | 13.07227209 | 1.372134839 | 8.33E-05 | 1.373787 | 1.377665879 | 1.409352327 |
| %RSD | 0.121699273 | -36.14210034 | 0.008332 | 32.21073 | 24.66864953 | 2.464713201 |

PT-002 Tccsis (SS) 152C He

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|----------|-------------|-------------|
| Range | 487 | 2.6632 | 0.0004 | 2.568181 | 2.384861535 | 1.059901936 |
| Average | 18465.22727 | -0.247504545 | 0.999964 | 2.568 | 10.30605402 | 64.91927729 |
| SD | 140.746365 | 0.706328181 | 8.81E-05 | 0.679222 | 0.627015225 | 0.229498985 |
| %RSD | 0.762223843 | -285.3798826 | 0.008814 | 26.44761 | 6.083950504 | 0.353514387 |

PT-010 Tccsis (AI) 152C He

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|----------|-------------|-------------|
| Range | 543 | 3.0158 | 0.0004 | 2.91198 | 2.717898492 | 1.324007618 |
| Average | 19121.63636 | 0.791877273 | 0.999981 | 2.912 | 11.4392872 | 65.942293 |
| SD | 157.2379625 | 0.833202011 | 8.52E-05 | 0.803074 | 0.746835017 | 0.315163048 |
| %RSD | 0.822303905 | 105.2185786 | 0.008519 | 27.57826 | 6.52868491 | 0.477937654 |

PT-005 GP50 7900 (SS) 152C He

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|----------|--------------|-------------|
| Range | 0.195 | 17.7235 | 0.0004 | 17.75109 | 17.78895114 | 18.08639731 |
| Average | 19.99822727 | -15.54061818 | 0.999941 | 16.760 | -3.421111635 | 51.65662998 |
| SD | 0.056179042 | 5.639235467 | 8.87E-05 | 5.649792 | 5.664302435 | 5.779377807 |
| %RSD | 0.280920108 | -36.28707302 | 0.008873 | 33.71094 | -165.5690617 | 11.18806591 |

PT-013 GP50 7900 (Al) 152C He

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|----------|-------------|-------------|
| Range | 1.991 | 3.4467 | 0.0202 | 3.886294 | 4.53612248 | 9.966794162 |
| Average | 20.93027273 | 2.568177273 | 0.991509 | 3.886 | 14.98487058 | 72.62092926 |
| SD | 0.659825058 | 1.232435744 | 0.006373 | 1.389124 | 1.616537808 | 3.421306189 |
| %RSD | 3.15249145 | 47.98873337 | 0.642774 | 35.74419 | 10.78779959 | 4.711184811 |

PT-007 GP50 189 (SS) 152C He

| | Slope (psia/V) | Intercept (psia) | R ² | 3 psia | 10 psia | 65 psia |
|----------------|----------------|------------------|----------------|----------|--------------|--------------|
| Range | 17285 | 25.799 | 0.0055 | 12.73128 | 12.71214415 | 12.56179955 |
| Average | 555528.7 | -93.18795 | 0.99866 | -442.726 | -435.947883 | -382.6873411 |
| SD | 6855.937289 | 5.7689341 | 0.001458 | 4.084001 | 4.049297869 | 3.822634361 |
| %RSD | 1.23412837 | -6.190643854 | 0.145949 | -0.92247 | -0.928849073 | -0.998892294 |

PT-003 MEMScap SP81 R (SS)

| | Slope (psia/V) | Intercept (psia) | R ² |
|----------------|----------------|------------------|----------------|
| Range | 3.64 | 0.0253 | 0 |
| Average | 573.93 | 3.77635 | 1 |
| SD | 1.82 | 0.01265 | 0 |
| %RSD | 0.317111843 | 0.334979544 | 0 |

PT-012 MEMScap SP81 R (AI)

| | Slope (psia/V) | Intercept (psia) | R ² |
|----------------|----------------|------------------|----------------|
| Range | 2.38 | 0.0177 | 0 |
| Average | 670.33 | -8.87895 | 1 |
| SD | 1.19 | 0.00885 | 0 |
| %RSD | 0.177524503 | -0.099673948 | 0 |

PT-007 MEMScap SP80 D (SS)

| | Slope (psia/V) | Intercept (psia) | R ² |
|----------------|----------------|------------------|----------------|
| Range | 7.87 | 0.285 | 0 |
| Average | 677.995 | -21.1135 | 0.9999 |
| SD | 3.935 | 0.1425 | 0 |
| %RSD | 0.580387761 | -0.674923627 | 0 |

PT-014 MEMScap SP80 D (AI)

| | Slope (psia/V) | Intercept (psia) | R ² |
|----------------|----------------|------------------|----------------|
| Range | 6.29 | 0.0643 | 0 |
| Average | 664.935 | -9.64385 | 1 |
| SD | 3.145 | 0.03215 | 0 |
| %RSD | 0.472978562 | -0.333373082 | 0 |

Reference

¹Oltman, S., “LAVA PT Trade Study,” NASA NIFS Report, 2016.